

# **Manual Policy**

The content of this manual is the property of Greco Systems, Prescott, Arizona, USA. Any reproduction of this information, without the express written permission of Greco Systems, is prohibited.

This manual is based on the facts available up to the time it was completed. While sincere efforts have been made to make it accurate, the information contained herein does not purport to cover all the details or variations in hardware, software, or firmware; nor to provide for every possible contingency in connection will installation, operation, maintenance, repair, or replacement. Also, features may be described herein, which are not present in all hardware, software, or firmware systems.

Greco Systems' policy is one of continuous improvement. The information in this manual is subject to change without notice, and should not be construed as a commitment by Greco Systems. Greco Systems also assumes no obligation to notify holders of this manual of subsequently made changes or updates.

Greco Systems makes no representation of warranty, expressed or implied, or statutory with respect to, or assumes responsibility for, the accuracy, completeness, sufficiency, or usefulness of this manual, nor of any problem that might arise from the use of the information in this manual.

The Greco Systems' CNC Minifile Operator's Manual Copyright © 1980 - 2004 Greco Systems. All rights reserved.

Greco-Net, Versa-Net, VersaFile, CNC Minifile and MINIFILE Plus are registered trademarks of Greco Systems.

IBM, XT, and AT are registered trademarks of International Business Machines Corporation.

VT100 is a registered trademark of Digital Equipment Corporation.

UNIX is a registered trademark of Bell Laboratories.

First Printing, April 1980

# Warranty Policy

## THE POLICY

Greco Systems warrants that all products manufactured by Greco Systems conform to published specification and are free from defects in materials and workmanship for a period of one (1) year from the date of delivery when used under normal operating conditions and within the service conditions for which they were furnished.

The obligation of Greco Systems arising from a Warranty claim shall be limited to repairing, or at its option, replacing without charge, any product which in Greco Systems' sole opinion proves to be defective within the scope of the Warranty. In the event Greco Systems is not able to modify, repair or replace, repair or replace non-conforming defective parts or components to a condition as warrantied within a reasonable time after receipt thereof, Greco Systems will refund the purchase price to the customer in return for the non-conforming or defective parts.

Greco Systems must be notified in writing of the defect or non-conformity within the Warranty period and affected product returned to Greco Systems' factory or to an authorized service center within (30) days after discovery of such defect or non-conformity.

For product warranties requiring return to Greco Systems, products must be returned to a service facility designated by Greco Systems. Buyer shall prepay shipping charges, taxes, duties and insurance for products returned to Greco Systems for warranty service.

Greco Systems shall have no responsibility hereunder for any defect or damage caused by improper storage, improper installation, unauthorized modification, misuse, neglect, inadequate maintenance, accident or for any; product which has been repaired or altered by anyone other than Greco Systems or its authorized representative and not in accordance with instructions furnished by Greco Systems.

## THE RETURN MATERIAL AUTHORIZATION

All returned equipment requires a Return Material Authorization (RMA) number to be issued by Greco Systems prior to shipping the equipment. To obtain this number, Buyer must provide Greco Systems with the product model numbers(s), serial number(s), problem statement and Buyer's contact person and telephone number.

## EXCLUSION OF OTHE WARRANTIES

THE WARRANTY DESCRIBED ABOVE IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND NO OTHER WARANTY, WHETHER WRITTEN OR ORAL, IS EXPRESSED OR IMPLIED. GRECO SYSTEMS SPECIFICALLY DISCLAIMS THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. No statement, representation, agreement, or understanding, oral or written, made by an agent, distributor, representative, or employee of Greco Systems, which is not contained in the foregoing Warranty; will be binding upon Greco Systems, unless made in writing and executed by an authorized Greco Systems employee. Under no circumstances shall Greco Systems be liable for any direct, indirect, special, incidental, or consequential damages, expenses, losses or delays (including loss of profits) based on contract, tort, or any other legal theory.

# **Table of Contents**

# 1. DESCRIPTION

1.1	OVERV	/IEW	1-1		
1.2	PORTABLE MINIFILE DESIGN				
	1.2.1	Front Panel	1-1		
	1.2.2	Rear Panel			
1.3	RACK-I	MOUNT MINIFILE DESIGN	.1-2		
	1.3.1	Front Panel	1-2		
	1.3.2	Rear Panel	1-2		

# 2 INSTALLATION

2.1	OVERV	)VERVIEW					
2.2	RECEIF	PT INSPEC	TION	.2-1			
2.3	MINIFIL	E CONFIG	URATION	.2-1			
	2.3.1	Serial Inter	face	.2-1			
		2.3.1.1	Serial Interface Installation	.2-1			
		2.3.1.2	Serial Interface Troubleshooting	.2-2			
	2.3.2	Parallel Int	erface	.2-2			
		2.3.2.1	Parallel Reader/Punch (PR/P) Installation	.2-2			
		2.3.2.2	PR/P Troubleshooting	.2-4			
2.4	MINIFIL	E INITIALI	ZATION	.2-5			
	2.4.1	Energizing	The Minifile	.2-5			
	2.4.2	Start-Up M	lessage	.2-5			

# 3. OPERATION

3.1	OVER\	/IEW .			3-1
3.2	DOS C	OMPA	<b>ATIB</b>	ILITY	3-1
3.3	DISK F	ORM	ATTI	NG AND FILE CREATION USING THE MINIFILE	3-2
	3.3.1	Form	attir	g A Diskette	3-2
	3.3.2	Crea	ting	A File	3-3
3.4	MINIFIL	_E CC	MM	ANDS OVERVIEW	3-3
3.5	FILE C	OMM/	٩ND	S	3-6
	3.5.1	1#	-	Define File	3-6
	3.5.2	2#	-	Select File (by File Number)	3-6
	3.5.3	3#	-	Close File	3-6
	3.5.4	7#	-	Select File (by File Name)	3-6
	3.5.5	20#	-	Copy File (by File Number)	3-6
	3.5.6	21#	-	Copy File (by File Name)	3-7
	3.5.7	98#	-	Delete File (by File Number)	3-7
	3.5.8	99#	-	Delete File (by File Name)	3-7
3.6	DISKE	TTE C	OM	MANDS	3-7
	3.6.1	4#	-	Free Blocks	3-7

	3.6.2	5#	-	Directory	3-8
	3.6.3	6#	-	Volume Identification	3-8
	3.6.4	91#	-	Format Diskette	3-8
	3.6.5	92#	-	Re-initialize Volume	3-8
	3.6.6	96#	-	Verify Disk	3-9
3.7	PARAN	ИЕТЕІ	R CO	OMMANDS	3-9
	3.7.1	22#	-	save Parameters to Disk	3-9
	3.7.2	23#	-	Restore Parameters from Disk	3-9
	3.7.3	40#	-	Display Parameters	3-9
	3.7.4	41#	-	Reset Parameters	3-10
	3.7.5	42#	-	Store Parameters	3-10
	3.7.6	43#	-	Channel 0 Baud Rate	3-10
	3.7.7	44#	-	Channel 1 Baud Rate	3-10
	3.7.8	45#	-	Channel 0 Parity	3-10
	3.7.9	46#	-	Channel 1 Parity	3-11
	3.7.10	47#	-	Channel 0 Protocol	3-11
	3.7.11	48#	-	Channel 1 Protocol	3-12
	3.7.12	49#	-	Active Channel	3-12
	3.7.13	51#	-	Text File Type	3-12
	3.7.14	52#	-	Line Feed Output	3-13
	3.7.15	53#	-	EIA Conversion	3-13
	3.7.16	55#	-	LF to CR Conversion	3-14
	3.7.17	57#	-	Channel 0 Auto Enable	3-14
	3.7.18	58#	-	Channel 1 Auto Enable	3-14
	3.7.19	61#	-	Channel 0 Stop Bits	3-15
	3.7.20	62#	-	Channel 1 Stop Bits	3-15
	3.7.21	65#	-	Channel 0 Data Bits	3-15
	3.7.22	66#	-	Channel 1 Data Bits	3-16
3.8	SPECI	AL PL	IRPO	DSE COMMANDS	3-16
	3.8.1	8#	-	Forward Search	3-16
	3.8.2	9#	-	Reverse Search	3-17
	3.8.3	50#	-	Date	3-17
	3.8.4	54#	-	Select Drive	3-17
	3.8.5	56#	-	Parallel Looping Option	3-18
	3.8.6	59#	-	LCD Adjustment	3-18
	3.8.7	60#	-	PROM ID Display	3-19
	3.8.8	67#	-	Nulls in Text File	3-19
	3.8.9	68#	-	Mazak Conversational Terminator	3-19
	3.8.10	69#	-	Serial Search	3-20
	3.8.11	70#	-	Numeric Input	3-20
	3.8.12	71#	-	Alphanumeric Input	3-20
	3.8.13	72#	-	Parallel Port Leader/Trailer Character	3-21
	3.8.14	73#	-	Reset	3-21

	3.8.15	74#	-	Part Program Pre-Display	3-21
	3.8.16	75#	-	Part Program Display	3-22
	3.8.17	80#	-	Parallel Switch Register	3-22
	3.8.18	82#	-	Parallel Reader Speed	3-22
	3.8.19	84#	-	Parallel Configuration Register (future use)	3-23
3.9	MINIFI	LE PL	US	COMMANDS	3-23
	3.9.1	30#	-	Network Communications	3-23
	3.9.2	31#	-	Editor Function	3-23
	3.9.3	32#	-	Network Default Drive	3-24
	3.9.4	33#	-	Editor Default Drive	3-24
	3.9.5	54#	-	Select Drive	3-25
	3.9.6	63#	-	Protocol PROM Version	3-25

# **APPENDIX A – SPECIFICATIONS**

A1.	PHYSICAL CONFIGURATION	A-1
A2.	INPUT POWER	A-1
A3.	ONLINE STATISTICS	A-1
A4.	ENVIRONMENT	A-2
A5.	DATA CHARACTERISTICS	A-2
A6.	INTERFACES	A-2

# **APPENDIX B – PROTOCOLS**

B1.	OVERVIE	W		B-1
B2.	MINIFILE	PROTO	COLS	B-1
B3.	PROTOC	OL SELE	CTION	B-2
	B3.1	0# -	No Protocol	B-2
	B3.2	1# -	X/On X/Off	B-2
	B3.3	2# -	Bridgeport Editor Port	B-2
	B3.4	3# -	Bridgeport DNC Loader	B-2
	B3.5	4# -	Bridgeport Easy Link	B-3
	B3.6	5# -	RS-491, Level II, Slave	B-3
	B3.7	6# -	Heidenhain	B-3
	B3.8	7# -	Punch/Reader	B-3
	B3.9	8# -	Synchronous Reader	B-4
	B3.10	9# -	RS-491, Level I	B-4
	B3.11	10# -	Fanuc	B-5
	B3.12	11# -	Heidenhain Block	B-5
	B3.13	12# -	FAPT	B-5
	B3.14	13# -	HECC 80	B-5
	B3.15	14# -	RS-491, Level II, Master	B-5
	B3.16	15# -	Hitachi Seiki	B-6

B3.17	16# - Mazak Conversational	B-6
B3.18	17# - Punch/Reader Master	B-6
B3.19	18# - X/On X/Off II	B-6
B3.20	19# - TLM	B-7
B3.21	20# - Sharmoa Remote	B-7
B3.22	21# - Fanuc Cassette	B-7
B3.23	22# - Mazak Cassette	B-7
B3.24	23# - Acramatic	B-7
B3.25	Host System (Optional)	B-8

# **APPENDIX C – ERROR MESSAGES**

C1.	OVER\	/IEWC-1
C2.	ERRO	R MESSAGES AND THEIR MEANINGSC-1
	C2.1	COMM ERROR
	C2.2	DATA OVERRUNC-1
	C2.3	DEFINED FILE ALRADY EXISTSC-1
	C2.4	DIRECTORY FAILURE
	C2.5	DISK READ ERRORC-1
	C2.6	DISK TIMEOUTC-1
	C2.7	END OF MEDIUMC-1
	C2.8	FILE DOES NOT EXISTC-1
	C2.9	FILE OPENC-1
	C2.10	INVALID COMMANDC-1
	C2.11	INVALID DATE ENTEREDC-1
	C2.12	INVALID DATE FORMAT DDMMYYC-1
	C2.13	INVALID FILE NUMBER ENTERED
	C2.14	INVALID VALUE ENTEREDC-2
	C2.15	READ-ONLY FILE
	C2.16	SYSTEM NOT CONFIGUREDC-2
	C2.17	THE DIRECTORY IS FULLC-2
	C2.18	TRACK SEEK ERRORC-2
	C2.19	WRITE PROTECTC-2

# APPENDIX D – MAINTENANCE AND SERVICE

D1.	OVERVIEW	/	D-1			
D2.	BASIC MAINTENANCE					
	D2.1	Minifile Exterior Maintenance	D-1			
	D2.2	Floppy Diskette Drive Read/Write Head Maintenance	D-1			
	D2.3	Baud	D-2			
D3	MINIFILE S	ERVICE	D-2			
	D3.1	Servicing Recommendations	D-2			
	D3.2	Minifile Repackaging Procedures	D-2			

# APPENDIX E – GLOSSARY OF TERMS

E1.	OVERVIEW	VE-1
E2.	TERMS AN	ID THEIR DEFINITIONS E-1
	E2.1	Argument E-1
	E2.2	ASCII (American Standard Code for Information Interchange) Code E-1
	E2.3	Baud E-1
	E2.4	Bit E-1
	E2.5	CNC (Computer Numerical Comtrol0 E-1
	E2.6	Command E-1
	E2.7	CR (Carriage Return) E-1
	E2.8	Data Bits E-1
	E2.9	DCE (Data Communications Equipment) E-1
	E2.10	DNC (Distributed Numerical Control; also, Direct Numerical Control) E-1
	E2.11	DTE (Data Terminal Equipment) E-1
	E2.12	EIA (Electronic Industries Association) Code E-1
	E2.13	Enter Key E-2
	E2.14	Erase Key E-2
	E2.15	File E-2
	E2.16	FormattingE-2
	E2.17	LF (Line Feed) E-2
	E2.18	NC (Numerical Control) E-2
	E2.19	Parallel Interface E-2
	E2.20	Parity E-2
	E2.21	Pointer
	E2.22	Protocol
	E2.23	RS-232-C
	E2.24	Serial InterfaceE-2
	E2.25	Stop Bits
APPE	NDIX F –E	EIA/ASCII/ISO CONVERSION CHART

F1.	OVERVIEW		F-1
F2.	EIA/ASCII/ISO	O CONVERSION CHART	F-1

# LIST OF FIGURES

1.2.1-1	Portable Minifile Front Panel1-1
1.2.2-1	Portable Minifile Rear Panel1-2
1.3.1-1	Rack-mount Minifile Front Panel1-2
2.5-1	Minifile Keypad2-6

# LIST OF TABLES

1.2.1-1	Front Panel Indicator Functions	.1-1
2.3.1.1-1	Channel 0 (DCE Female) Signals	.2-2
2.3.1.1-2	Channel 1 (DTE male) Signals	2-2
2.3.1.2-1	RS-232-C Troubleshooting Chart	.2-2
2.3.2.2-1	PR/P Troubleshooting Chart	.2-5
3.2-1	Minifile Diskette Characteristics	3-1
3.4-1	Numerical Commands List	.3-4
3.7.14-1	Valid 52# and 55# Relationships	3-13
3.8.12-1	Alphanumeric Entries	3-20

# 1. **DESCRIPTION**

## 1.1 OVERVIEW

Greco Systems' compact CNC MINIFILE is a disk-based part program memory system which eliminates paper tape and interfaces with virtually any NC/CNC control or CAD/CAM system. Originally designed as a replacement for paper tape equipment, and the Minifile has been continually improved to meet requirements for a simple, reliable method to manage part programs for numerically controlled machine tools. As a stand-alone device, the Minifile provides capabilities to greatly enhance machine shop productivity and efficiency.

The Minifile is designed to be versatile, compact, shock resistant and lightweight and is available in portable and rack-mount models.

## 1.2 PORTABLE MINIFILE DESIGN

## 1.2.1 Front Panel

The portable Minifile front panel (Fig. 1.2.1-1) contains the floppy diskette slot(s), Liquid Crystal Display (LCD), keypad, and indicator lamps. Indicator lamp functions are described in Table 1.2.1-1.

## Figure 1.2.1-1. Portable Minifile Front Panel



Table 1.2.1-1. Front Panel Indicator Functions

Indicator Name	Color	Function	
ACTIVITY	Red	Lighted when data is being transmitted or received.	
POWER	Green	Lighted when unit On.	
FILE OPEN	Red	Flashes when a file is opened for reading or writing.	
(None)	Red	Located on the floppy diskette drive; lighted (flashing) when data blocks are being written to, or read from, the diskette	

## 1.2.2 Rear Panel

The rear panel of the portable Minifile (Fig. 1.2.2-1) contains the Channel 0 and Channel 1 connectors, a male plug for line cord connection, an AC Power ON/OFF switch, an air circulating fan (with filter), a fuse holder, and, if specified, the optional Parallel Reader/Punch Emulator (PR/P) connector (Channel 2).





## 1.3 RACK-MOUNT MINIFILE DESIGN

## 1.3.1 Front Panel

The rack-mount Minifile front panel (Fig. 1.3.1-1) contains the floppy diskette slot(s), Liquid Crystal Display (LCD), Keypad, AC POWER ON/OFF switch, Channel 1 connector, and indicator lamps. Indicator lamp functions are described in Table 1.2.1-1 above.

## Figure 1.3.1-1. Rack-mount Minifile Front Panel



## 1.3.2 Rear Panel

The rear panel of the rack-mounted Minifile (Fig. 1.3.2-1) contains a male plug for line cord connection, an air circulating fan (with filter), a fuse holder, the Channel 0 connector, and, if specified, the optional Parallel Reader/Punch (PR/) connector (Channel 2).

# 2. INSTALLATION

## 2.1 OVERVIEW

This section describes receipt inspection procedures, installation and configuration procedures, Minifile initialization, and keypad operation. Any problems encountered while installing and configuring the CNC MINIFILE can be solved by telephoning the Greco Systems' Customer Service Department at (800) 23-GRECO (800-234-7326).

## 2.2 RECEIPT INSPECTION

Perform the following when removing the Minifile from the shipping carton:

- 1. Check the shipping carton for damage. If there are any signs of rough handling, save the carton for evidence. If storage is not a problem, it is recommended that the shipping carton and padding be saved in the event the unit needs to be re-shipped.
- 2. Remove the Minifile from the carton, remove the foam padding, then remove the plastic bag.
- 3. Check the Minifile for any evidence of physical damage. If there are any signs of damage, notify the carrier.

## CAUTION

Do not operate a Minifile that has been damaged in shipment. The Minifile could be further damaged or may damage electrical devices connected to it.

- 4. Open each floppy disk drive slot hatch and remove the protective insert from each drive by pulling the tab that projects from the drive slot.
- 5. Install the AC power cord.

## 2.3 MINIFILE CONFIGURATION

## 2.3.1 Serial Interface

The Minifile has two bi-directional RS-232-C Serial Interface ports (Channel 0 and Channel 1). However, Channel 1 may be dedicated either to the Editor or to the Network Control Protocol, depending upon the configuration. Both Serial interface connectors are located on the rear panel of the portable Minifile. The rack-mount Minifile has the Channel 0 connector on the rear panel and the Channel 1 connector on the front panel.

## 2.3.1.1 Serial Interface Installation

Both serial channels conform to the EIA RS-232-C standard. Channel 0 is wired as a modem (DCD) port and has a 25-pin DB25S (female) connector. Channel 1 is wired as a terminal (DTE) port and has a 25-pin DB25P (male) connector. Channel 0 signal definitions are provided in Table 2.3.1.1-1 and Channel 1 signal definitions are provided in Table 2.3.1.1-2.

Pin	Direction	Signal Name	Comments
1	N/A	Protective Ground	
2	Input	TXD (Transmit Data)	
3	Output	RXD (Receive Data)	
4	Input	RTS (Request to Send)	See Note below.
5	Output	CTS (Clear to Send)	Always true (MARK).
6	Output	DSR (Data Set Ready)	Always true (MARK).
7	N/A	SG (Signal Ground)	N/A
8	Output	DCD (Data Carrier Detect)	Always true (MARK).
20	Input	DTR (Data Terminal Ready)	Always ignored.

## Table 2.3.1.1-1. Channel 0 (DCE Female) Signals

## <u>NOTE</u>

When Protocol 8 or 9 is selected (see Appendix B), the RTX input signal controls data transmission from the Minifile. When it is true (MARK), the Minifile transmits data. With all other protocols the RTS input signal is ignored.

Table 2.3.1.1-2.	Channel 1	(DTE Male	) Signals
------------------	-----------	-----------	-----------

Pin	Direction	Signal Name	Comments
1	N/A	Protective Ground	
2	Output	TXD (Transmit Data)	
3	Input	RXD (Receive Data)	
4	Output	RTS (Request to Send)	Always true (MARK).
5	Input	CTS (Clear to Send)	See Note below.
6	Input	DSR (Data Set Ready)	Always ignored.
7	N/A	SG (Signal Ground)	
8	Input	DCD (Data Carrier Detect)	See Note below.
20	Output	DTR (Data Terminal Ready)	Always true (MARK).

## <u>NOTE</u>

When Protocol 9 is selected (see Appendix B), the CTS input signal controls data transmission from the Minifile. When it is true (MARK), the Minifile transmits data. With all other protocols the CTS and DCD input signals are ignored.

When Protocol 9 is selected, the DCD input controls data recording by the Minifile. When this signal is false (LOW), the Minifile does not record data and the ACTIVITY indicator does not light.

## 2.3.1.2 Serial Interface Troubleshooting

The RS-232-C is a well-tested standard interface; however, even this interface can cause installation problems. To assist in isolating basic problems on the system a list of steps is provided in Table 2.3.1.2-1. These steps should be performed in sequence and the appropriate Application Note should be used to check all procedures. If the information in

Table 2.3.1.2-1 does not solve the problem, contact the Greco Systems' Customer Service Department.

Problem	Possible Solution
Attempt to read or write a file causes no activity	<b>Ensure</b> the correct channel has been selected. <b>Ensure</b> the correct protocol has been selected. <b>Review</b> the Machine Tool Control (MTC) setup, including parameters, jumpers, connectors, and switch setting.
Minifile or MTC produces communication error.	<b>Ensure</b> the Minifile and the MTC agree on baud rate, data bits, stop bits, and parity. If not, change the Minifile settings to agree with the MTC, even if changes do not agree with the Application Note (please notify the Greco Systems' Customer Service Department of the discrepancy.
MTC produces a parity error.	<b>Ensure</b> the Minifile has the correct parity selection. <b>Ensure</b> the MTC and the Minifile have the same data type (ASCII or EIA).
ACTIVITY indicator is lighted, but the Minifile does not record data.	<b>Ensure</b> that control codes are enabled on the MTC. <b>Ensure</b> the correct channel has been selected. <b>Ensure</b> the Minifile has the correct protocol. Ensure the MTC and Minifile agree on baud rate.

## Table 2.3.1.2-1. RS-232-C Troubleshooting Chart

## 2.3.2 Parallel Interface

The bi-directional Parallel Reader/Punch (PR/P) Interface on the Minifile is designed specifically to replace paper tape readers and punches. The PR/P uses a female 50-pin Telco-type connector for tape reader and tape punch emulation. Interface characteristics such as reader speed, signal timing, and signal polarity are programmed via the keypad (see Section 2.5 for keypad operation). These commands allow simulation of a wide variety of paper tape equipment and other types of equipment such as parallel printers.

Greco Systems supplies adapter cables that provide the connection between he Minifile standard 50pin parallel port and the tape reader and/or tape punch cable. For some interfaces, the adapter cable incorporates additional electronics to provide special functions such as simulating mechanical reader contacts. The adapter cable makes the Minifile plug-compatible with the reader or punch being replaced, so the installation can be performed by simply unplugging a cable from the reader or punch and plugging it into the end of the adapter cable.

## 2.3.2.1 Parallel Reader/Punch (PR/P) Installation

The Minifile is normally shipped with a specific Application Note for each reader, punch or reader/punch configuration. This Application Note provides instructions on connecting and configuring the Minifile, as well as setting up the connected device(s). The Application Note also provides the part number for the correct Greco Systems interface cable.

## WARNING

## Unlike RS-232-C interfaces, the voltages in parallel applications can involve potential shock hazards. If you have any questions, or if something does not appear correct, call Greco Systems' Customer Service Department before installing the system.

## A. Tape Reader Emulation

To operate as a paper tape reader:

- 1. Connect the adapter cable in accordance with the Application Note.
- 2. Enter the correct parameters from the Application Note for the reader being emulated.
- 3. Use the **2**# or **7**# command to select the file (see Section 4.4 for command definitions).
- 4. Transfer the data (upload) to the machine control, or other device, exactly as if a tape reader were being operated.

## B. Tape Punch Emulation

To operate as a tape punch:

- 1. Connect the adapter cable in accordance with the Application Note.
- 2. Enter the correct parameters from the Application Note for the punch being emulated.
- 3. Use the #1 command to define the file (see Section 3, paragraph 3.3.2).
- 4. Transfer the data (download) to the Minifile. The ACTIVITY indicator will be lighted while data are being transferred.
- 5. After the data transfer has been completed, enter the Close File (**3**#) command to close the file.

## 2.3.2.2 PR/P Troubleshooting

The PR/P Interface has been thoroughly tested; however, there can be interface problems during installation. One of the most common problems is caused by attempting to replace a malfunctioning reader, punch, or reader/punch with a Minifile. If the problem is not corrected, the same problem that affected the previous operation may affect the Minifile.

Other common problems are listed in Table 2.3.2.2-1. In this table, the **80**# command (Parallel Switch Register) is frequently listed as the possible solution. The format for the argument for this command is the following 16-bit entry:

16			1
0000	0000	0000	0000

The meaning of the bits depends upon the setting of the Parallel Switch Register (80# command) mode.

If the Possible Solution in Table 2.3.2.2-1 does not solve the problem, call Greco Systems' Customer Service Department.

Problem	Possible Solution
ACTIVITY indicator does not light.	<b>Ensure</b> the Minifile parameters are correct. <b>Ensure</b> the cabling is correct and fully seated. <b>Ensure</b> the MTC setup is functioning correctly. <b>Ensure</b> the MTC is being operated exactly as if a paper tape reader/punch is connected.
ACTIVITY indicator lights, and stays lighted, when a file is opened.	<b>Close</b> the file, reset the controller, then reopen the file. <b>Change</b> Bit 10 of the <b>80#</b> command so it reverses its present state.
ACTIVITY indicator lights when read is started, but does not go out. There is no noticeable data transmission.	<ul><li>Change Bits 3 and 13 of the 80# command. Try all possible combinations.</li><li>Check the data with paper tape for proper start, stop and rewind codes.</li></ul>
When a file is opened, the FILE OPEN indicator lights and stays lighted, rather than flash.	Enter the 82# command and ensure it shows the correct speed. If there is no recommended speed, set the speed within the 100-300 range.
ACTIVITY indictor flashes when a read is initiated, goes off, and there is no error reported by the host system.	Enter the 80# command. If Bit 2 is a zero, change the bit to a one.

## Table 2.3.2.2-1. PR/P Troubleshooting Chart

## 2.4 MINIFILE INITIALIZATION

## 2.4.1 Energizing The Minifile

## WARNING

## Do not remove the Minifile's cover, as a potential shock hazard is present.

Perform the following:

- 1. Plug in the Minifile to the appropriate AC outlet, preferably on the MTC AC Circuit Panel outlet.
- 2. Turn the AC POWER switch to ON.

## 2.4.2 Start-Up Message

When the Minifile is turned on, the ACTIVITY, FILE OPEN, and diskette drive indicators will momentarily light (red), the POWER indicator will light (green), and the display will read:

## **GRECO SYSTEMS xy**

CNC-200 V02.82

The "xy" in this display indicates the enabled options.

If the space occupied by the "x" is:

Ν	-	The Network Control Protocol is enabled (separate documentation is provided).
Ε	-	The Editor is enabled (separate documentation is provided).
Blank	-	The Network Control protocol and the Editor are not enabled

If the space occupied by the "y" is:

Н	-	The Host Control Protocol is enables (separate documentation is provided).
Blank	-	The Host Control Protocol is not enabled.

The keypad (Fig.2.5-1) provided:

- The numbers required to specify the commands;
- The Enter Key (# pound sign), used to enter the commands; and
- The Erase Key (\* -asterisk), used to either erase commands before the pound sign enters them or to cancel entered commands.

Figure 2.5-1. Minifile Keypad

For example, to change the baud rate parameter for Channel 0 to 9600 from its previous setting, the following three keys would be pressed on the keypad:

## 43#

Most of the commands entered require further information, called an "argument." When an argument is required, the Minifile displays a short line at the bottom of the display screen and waits for entry of the required information. For example, after entering the "43#" above to select the baud rate parameter for Channel 0, the following would be entered to set the new baud rate:

## 9600#

## 3.1 OVERVIEW

This section describes the compatibility of the Minifile with the Disk Operating System (DOS), floppy diskette information, diskette formatting, and file creation.

This section also provides a numerical listing of all the commands used by the Minifile, followed by an explanation of the commands.

## 3.2 DOS COMPATIBILITY

The DOS system used by the Minifile -AT is compatible with the IBM-AT, and the Minifile -XT is compatible with the IBM-XT (see Table 3.2-1 for diskette compatibility). The Floppy diskette format used by the Minifile models -XT, -3, -AT, and -S2 are compatible with IBM or MicroSoft DOS 360FK, 720FK, 1.2M and 1.44M formats respectively.

The Minifile uses double-sided floppy diskettes with a soft sector format. To acquire maximum density diskettes that have been tested for formatting capabilities, contact the Greco Systems' Customer Service Department at 9800) 23-GRECO (800-234-7326).

## CAUTION

Ensure the correct diskette is used for the Minifile model. The wrong diskette type can cause serious read and/or write problems.

1	1				1
Model	Tracks/ Side	Tracks/ Side	Formatted Diskette Capacity	Paper Tape	Remarks
P-XT	40	48	360 KB	3,000'	5.25" diskette (9 sectors – double sided, double density); IBM-XT compatible.
P-3	80	134	720 KB	6,000'	3.5" diskette (9 sectors – double sided, double density), IBM compatible
P-AT	80	96	1.2 MB	10,000'	5.25" diskette (156 sectors – double sided, high density), IBM-AT compatible.
P-S2	80	135	1.44 MB	12,000'	3.5" diskette (18 sectors – double sided, high density), IBM PS/2 compatible.

## Table 3.2-1. Minifile Diskette Characteristics

There are certain criteria to remember when preparing Minifile data on an IBM computer:

- 1. Use the standard IBM directory structure without subdirectories. Therefore, do not use the **MKDIR** command.
- 2. To name a volume from the computer, use /V with the **FORMAT** command for example:

## FORMAT (a:)/V

3. File names are required; Extensions, up to three letters, are optional. Both can be alphanumeric, but the alphabetic characters must be in upper case. For example:

## MACH01

4. The Minifile supports text and binary files. Text files use standard ASCII, but without NUL (null) characters. Binary files close when that number of characters have been read. Text files close when that number of the SUB (substitute) character is read. The Minifile assumes all files other than those with the .BIN extension are Text files.

With text files (any file without the .BIN extension), the Minifile reads the number of characters within the text file and directory then counts the characters as the file is read. The Minifile stops reading when that number is reached or the SUB character is read, whichever comes first. When writing or reading a text file without an extension, the Minifile adds the .TXT extension to the file name if Text File Type is enabled or will add the .BIN extension if Text File Type is disabled. Text files contain 7-bit data, usually limited to the ASCII characters, **CR**, **LF**, and **SUB**.

Binary files can contain any combination of 8-bit data, making up to 256 possible characters. Since binary files do not use the SUB character to mark the EOF (End Of File), the Minifile exclusively uses the character count from the directory to know when to stop reading

## 3.3 DISK FORMATTING AND FILE CREATION USING THE MINIFILE

## 3.3.1 Formatting A Diskette

A new diskette must be formatted before it can be used. Formatting organizes the storage locations and writes data onto the diskette, including the directory and the volume label.

## CAUTION

# If a diskette containing data is reformatted, all data stored on the diskette will be lost.

To format a diskette, perform the following:

- 1. Install the diskette to be formatted in the active drive.
- 2. Enter the following via the keypad (see 3.6.4):

## 91#

3. Enter a volume name. For example:

## 123#

The diskette drive indicator lamp will be lighted until the formatting is completed. **<u>Do not</u>** enter any other commands via the keypad while the diskette is being formatted.

## 3.3.2 Creating A File

Where:

To create a file with an alphanumeric name, perform the following:

1. Set the keypad to allow alphabetic characters by entering the following via the keypad (see 3.8.12):

## 71#

2. Enter the following via the keypad (see 3.5.1):

## 1#

3. Enter a file name. For example, to enter **MACH01**, enter the following via the keypad (see 3.8.12):

## 221012170001#

22 = M
10 = A
12 = C
17 = H
00 = 0
01 = 1

## <u>NOTE</u>

When the first digit of the two-digit entry is pressed, nothing will be displayed on the LCD. When the second digit is pressed, the alphanumeric equivalent will be displayed on the LCD. For the above example, the letter "M" would be entered as "22" with the first"2" not being displayed and the second "2" causing the letter "M" to be displayed on the LCD; then the letter "A" would be entered as "10" with the "1" not being displayed and the "0" causing the letter "A" to be displayed on the LCD following the "M," etc.

If the file opens properly, the FILE OPEN indicator will flash.

To close the file, enter the following via the keypad (see 3.5.3):

## 3#

## 3.4 MINIFILE COMMANDS OVERVIEW

The commands used by the Minifile are organized into group:

- File Commands (Section 3.5).
- Diskette Commands (Section 3.6).
- Parameter Commands (Section 3.7).
- Special purpose Commands (SPC) (Section 3.8).
- Minifile Plus (MF Plus) Commands (Section 3.9)
- Net Commands (explained in the Versa-Net or Greco-Net Operator's Manual, as applicable).

Table 3.4-1 provides a listing of all the commands used by the Minifile.

## Table 3.4-1. Numerical Commands List

Command	#Command Name	Group
1#	Define File	File
2#	Select File (by File Number)	File
3#	Close File	File
4#	Free Blocks	Diskette
5#	Directory	Diskette
6#	Volume ID	Diskette
7#	Select File (by File Label)	File
8#	Forward Search	SPC
9#	Reverse Search	SPC
10#	Cancel Redirection	Net*
20#	Copy File (by File Number)	File
21#	Copy File (by File Name)	File
22#	Save Parameters from Disk	Parameter
23#	Restore Parameters from Disk	Parameter
30#	Network Communications	MF Plus
31#	Editor Function	MF Plus
32#	Network Default Drive	MF Plus
33#	Editor Default Drive	MF Plus
40#	Display Parameters	Parameter
41#	Reset Parameters	Parameter
42#	Store Parameters	Parameter
43#	Channel 0 Baud Rate	Parameter
44#	Channel 1 Baud Rate	Parameter
45#	Channel 0 Parity	Parameter
46#	Channel 0 Protocol	Parameter
47#	Channel 0 Protocol	Parameter
48#	Channel 1 Protocol	Parameter
49#	Active Channel	Parameter
50#	Enter Date	SPC
51#	Text File type	Parameter
52#	LF Output	Parameter
53#	EIA Conversion	Parameter
54#	Select Drive	SPC/MF Plus
55#	LF to CR Conversion	Parameter
56#	Parallel Looping Option	SPC
57#	Channel 0 Auto Enable	Parameter
58#	Channel 1 Auto Enable	Parameter
59#	LCD Adjustment	SPC

Command	#Command Name	Group
60#	PROM ID Display	SPC
61#	Channel 0 Stop Bits	Parameter
62#	Channel 1 Stop Bits	Parameter
63#	Protocol PROM Version	MF Plus
65#	Channel 0 Data Bits	Parameter
66#	Channel 1 Data Bits	Parameter
67#	Nulls in Text File	SPC
68#	Mazak Conversational Terminator	SPC
69#	Serial Search	SPC
70#	Numeric Input Character	SPC
71#	Alphanumeric Input	SPC
72#	Parallel Port Leader/Trailer Character	SPC
73#	Reset	SPC
74#	Part Program Pre-Display	SPC
75#	Part Program Display	SPC
80#	Parallel Switch Register	SPC
82#	Parallel Reader Speed	SPC
84#	Parallel Configuration Register	SPC
85#	Parts.Job Download Request	Net*
86#	Parts.Job Upload Request	Net*
87#	Download Request	Net*
88#	Upload Request	Net*
89#	Device.Job File Redirection	Net*
91#	Format Diskette	Diskette
92#	Re-initialize Volume	Diskette
96#	Verify Diskette	Diskette
98#	Delete File (by File Number)	File
99#	Delete File (by File Label)	File

\* -Refer to the Versa-Net or Greco-Net Operator's Manual, as appropriate.

The File Commands are used to record, read, transmit, and delete diskette files.

3.5.1	1# - De	efine File
	Purpose:	To open and name a file for recording.
	Display:	DEFINE FILE:
	Argument:	File name (without an extension of up to eight alphabetic, numeric, or alphanumeric characters
		The Minifile appends the extension <b>.TXT</b> if Text File Type (see 3.7.13) is enabled. It appends the extension <b>.BIN</b> if Text File Type is disabled.
	Argument:	<ul><li>File name (without an extension of up to eight alphabetic, numeric, or alphanumeric characters</li><li>The Minifile appends the extension <b>.TXT</b> if Text File Type (see 3.7.1 enabled. It appends the extension <b>.BIN</b> if Text File Type is disabled.</li></ul>

3.5.2	2# - Select File (by File Number)	
	<b>Purpose:</b> To open a file by file number for transmission.	
	Display:	SELECT FILE:
	Argument:	Entry number that designates the file's position in the directory.
3.5.3	3# - Close File	
	Purpose:	To manually close a file.
	Display:	CLOSE FILE:
	Argument:	No argument required, but do not enter another command until this operation is completed.
3.5.4	7# - Select File (by File Name)	
	Purpose:	To open a file by file name for transmission.
	Display:	SELECT FILE:
	Argument:	The file name (without an extension) as it appears in the directory; an extension is automatically assumed.

The extension of the file name on the diskette must be **.BIN** or **.TXT**. The Minifile looks for the entered file name with one of these extensions, depending upon the currently selected file type as determined by the **51**# command. If Text File Type (see 3.7.13) is enabled, the Minifile looks for the file name with the extension **.TXT**. If the Text File Type is disabled, the Minifile looks for the file name with the extension **.BIN**.

## 3.5.5 20# - Copy File (by File Number)

**Purpose:** To copy a file to a diskette by file number (for the dual-drive Minifile only).

**Display:** COPY FILE: **Argument:** The file number as it appears in the directory. The file number of the file being copied to diskette will be displayed. The diskette drive indicator lamps will flash until the copying is completed. **Do not** enter any other commands via the keypad while the file is being copied. 3.5.6 21# - Copy File (by File Name) **Purpose:** To copy a file to a diskette by file name (for the dual-drive Minifile only). **Display:** COPY FILE: **Argument:** The file name as it appears in the directory (include extension, if any). The file name of the file being copied to the diskette will be displayed. The diskette drive indicator lamps will flash until the copying is completed. Do **not** enter any other commands via the keypad while the file is being copied. 3.5.7 98# - Delete File (by File Number) To delete a file (except read-only) by file number from the diskette. This **Purpose:** command should not be entered when performing alphanumeric input, as the file number can be the numerical equivalent of the entered alphabetic. **Display: DELETE FILE: Argument:** The entry number that designates the file's position in the directory 3.5.8 99# - Delete File (by File Name) **Purpose:** To delete a file (except read-only) by file name from the diskette. **Display: DELETE FILE: Argument:** The file name (without an extension) as it appears in the directory; an extension is automatically assumed. The extension of the file name on the diskette must be .BIN or .TXT. The Minifile looks for the entered file name with one of these extensions, depending upon the currently selected file type as determined by the 51# command. If Text File Type (see 3.7.13) is enabled, the Minifile looks for the file name with the extension **.TXT**. If the Text File Type is disabled, the Minifile looks for the file name with the extension **.BIN**.

## 3.6 DISKETTE COMMANDS

The Diskette Commands are used to format and verify diskettes, as well as display their attributes.

## 3.6.1 4# - Free Blocks

**Purpose:** To display the total number of blocks and the total number of unused blocks on a diskette.

	Display:	FREE BLOCKS, the VOLUME NAME then, after calculations, TOTAL NNN and UNUSED NNN
	Argument:	No argument required.
3.6.2	5# - Directory	
	Purpose:	To display the diskette file directory.
	Display:	DIRECTORY, followed by the first file's information:
		<ul> <li>Entry number that designates the file's position in the directory.</li> <li>Date entered.</li> <li>Number of blocks in the file.</li> <li>File name.</li> </ul>
		To display the same information for the next file, press the Enter Key (#). The entry number is used to identify the file using the <b>2</b> #, <b>20</b> # and <b>98</b> # commands.
	Argument:	No argument required.
3.6.3	6# - Volume Identification	
	Purpose:	To display the diskette volume name and the number of files on the diskette.
	Display:	VOLUME ID, the name of the volume, then FILES: followed by the number of files in the volume.
	Argument:	No argument required.
3.6.4	91# - Format Diskette	
	Purpose:	To format a new diskette, or to reformat a used diskette, to read and write data.
	Display:	VOLUME NAME:
	Argument:	Volume name of up to 11 alphabetic, numeric, or alphanumeric characters, without spaces.
3.6.5	92# -	Re-initialize Volume
	Purpose:	To re-initialize a volume by erasing the directory and re-naming the volume. Old data is no longer accessible, but the volume is ready for new data storage.
	Display:	VOLUME NAME:
	Argument:	Volume name of up to 11 alphabetic, numeric, or alphanumeric characters, without spaces.

## 3.6.6 96# - Verify Disk

Purpose:	To verify the readability of the diskette by performing a read check on all the blocks. The display to the left of READ is the block number being read; to the right of READ is the number of read failures; and to the right of SEEK the number of seek failures. If no value appears after READ or SEEK, there have been o failures. The Minifile performs this non-destructive test once then displays the results. The Minifile must be reset with a Reset command ( <b>73#</b> -0 see 3.8.12) to leave this command.	
Display:	VERIFY DISK, then READ SEEK	
Argument:	No argument required.	

## 3.7 PARAMETER COMMANDS

The Parameter Commands configure the Minifile to communicate with a host system. <u>Refer to the Application</u> <u>Note supplied with the Minifile before using these commands.</u>

3.7.1	7.1 22# - Verify Disk	
	Purpose:	To write the active parameters to a diskette. Very useful with the portable Minifile if there are numerous devices which use different parameters.
	Display:	SAVE PARM FILE:
	Argument:	file number or name (without extension). Minifile adds the extension <b>.MFP</b> to the file. The diskette drive indicator lamp will be lighted until the copying is completed. <b>Do not</b> enter any other commands via the keypad while the file is being copied.
3.7.2	23# - R	estore Parameters from Disk
	Purpose:	To set the active parameters by reading the parameters from the diskette. Very useful with the portable Minifile if there are numerous devices which use different parameters.
	Display:	RESTORE PARM FILE:
	Argument:	No argument required. After the selected channel is displayed, press the Enter Key (#) to sequence through the remaining active parameters.

# 3.7.3 40# - Display Parameters Purpose: To display the present operating parameters for the selected channel. Display: DISPLAY PARAMS Argument: No argument required. After the selected channel is displayed, press the Enter Key (#) to sequence through the remaining active parameters.

## 3.7.4 41# - Reset Parameters

**Purpose:** To reset the system to the parameters in non-volatile memory.

**Display:** RESET PARAM

Argument: No argument required. The display returns to the initial Power On display.

## 3.7.5 42# - Store Parameters

Purpose:	To store operating parameters in non-volatile memory.
Display:	STORING PARAMS
Argument:	No argument required. <b>Do not</b> enter any other commands until the above display clears.

3.7.6	43# -	Channel 0 Ba	aud Rate	
	Purpose:	To display of	r change the Chanr	nel 0 baud rate.
	Commands:	<b>43</b> ## = displ <b>43</b> # = selects	ays the current para s parameter for sett	ameter setting. ing.
	Display:	CHANNEL	0 BAUD	
	Argument:	To make a cl	hange, enter one of	the following:
		50#	600#	2000#
		75#	750#	2400#
		110#	1000#	3000#
		135#	1200#	3600#
		150#	1500#	4800#
		300#	1800#	7200#
				9600#

To display the present value, and to change the value, enter the command and argument in sequence.

3.7.7	44# - Channel 1 Baud Rate	
	Purpose:	To display or change the Channel 1 baud rate.
	Commands:	<ul><li>44## = displays the current parameter setting.</li><li>44# = selects parameter for setting.</li></ul>
	Display:	CHANNEL 1 BAUD
	Argument:	See 3.7.6 Argument.

## 3.7.8 45# - Channel 0 Parity

**Purpose:** To display or change the present parity value for Channel 0.

Commands:	<ul><li>45## = displays the current parameter setting.</li><li>45# = selects parameter for setting.</li></ul>
Display:	CHN0 0=N 1=0 2=E 3=M 4=S:
Argument:	To make a change, enter one of the following: 0# for No parity 1# for Odd Parity 2# for Even Parity 3# for Mark (sets the eighth bit) 4# for Space (clears the eighth bit) To display the present value, and to change the value, enter the command and argument in sequence.

## 3.7.9 46# - Channel 1 Parity

Purpose:	To display or change the present parity value for Channel 1.
Commands:	<ul><li>46## = displays the current parameter setting.</li><li>46# = selects parameter for setting.</li></ul>
Display:	CHN1 0=N 1=0 2=E 3=M 4=S:
Argument:	See 3.7.8 Argument.

## 3.7.10 47# - Channel 0 Protocol

Purpose:	To display or change the protocol selection for Channel 0.		
Commands:	<ul><li>47## = displays the current parameter setting.</li><li>47# = selects parameter for setting.</li></ul>		
Display:	CHAN 0 PROTOCOL		
Argument:	To make a change, enter one of the following:		
	0# = No protocol $13#$ = HECC 80		
	1# = X/On X/Off $14# = RS-491$ , Level II, Master		
	2# = Bridgeport Editor Port 15# = Hitachi Seiki		
	3# = Bridgeport DNC Loader 16# = Mazak Conversational		
	4# = Bridgeport Easy Link 17# = Punch/Reader Master		
	5# = RS-491, Level II, Slave $18#$ = X/On X/Off II		
	6# = Heidenhain $19#$ = TLM		
	7# = Punch/Reader 20# = Sharnoa Remote		
	8# = Synchronous Reader 21# = Fanuc Cassette		
	9# = RS-491, Level I $22#$ = Mazak Cassette		
	10# = Fanuc $23#$ = Acramatic		
	11# = Heidenhain Block 24# = Host System (optional)		
	12# = FAPT		

To display the present value, and to change the value, enter the command and argument in sequence.

3.7.11	48# -	Channel 1 Protocol	
	Purpose:	To display or change the protocol selection for Channel 1.	
	Commands:	<ul><li>48## = displays the current parameter setting.</li><li>48# = selects parameter for setting.</li></ul>	
	Display:	CHAN 1 PROTOCOL	
	Argument:	See 3.7.10 Argument.	

## 3.7.12 49# - Active Channel

Purpose:	To display or change the channel used to transmit and receive data.
Commands:	<ul><li>49## = displays the current parameter setting.</li><li>49# = selects parameter for setting.</li></ul>
Display:	SELECTED CHANNEL
Argument:	To change, enter one of the following:
	0#
	1#
	2# (if configured)

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.7.13 51# - Text File Type

Purpose:	To display or change the file type. The file type can be binary (.BIN) or text (.TXT). The Minifile Editor requires a text file.
Commands:	<ul><li>51## = displays the current parameter setting.</li><li>51# = selects parameter for setting.</li></ul>
Display:	TEXT $0 = DIS 1 = EBL$
Argument:	To make a change, enter one of the following:
	0# = Disable the text file capability. 1# = Enable the text file capability.
	To display the present value, and to change the value, enter the command argument in sequence.

## 3.7.14 52# - Line Feed Output

**Purpose:** To transmit or strip the LF (Line Feed) character after a CR (Carriage Return) has been transmitted (this command affects text type files only).

When CR and LF are both present in the file, 52# and 55# have the effect shown in Table 3.7.14-1 during output. Enabled/Enabled results in both being sent.

52#	55#	Activity
Dischlod	Dischlad	CR is transmitted.
Disabled	Disabled	LF is not transmitted.
Enabled	Dischlod	CR is transmitted.
Enabled	Disabled	LF is transmitted.
Dischlad	Fraklad	CR is not transmitted.
Disabled	Enabled	LF is transmitted.
Enabled	Enabled	Not applicable.

 Table 3.7.14.1
 Valid 52# and 55# Relationships

Commands:	<ul><li>52## = displays the current parameter setting.</li><li>52# = selects parameter for setting.</li></ul>
Display:	LF  0 = DIS  1 = EBL
Argument:	To control LF transmission, enter one of the following:
	0# = Disabled. 1# = Enabled.

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.7.15 53# - EIA Conversion

Purpose:	To convert data from EIA code to ASCII code when recording and to convert data from ASCII code to EIA code when transmitting.
Commands:	<ul><li>53## = displays the current parameter setting.</li><li>53# = selects parameter for setting.</li></ul>
Display:	EIA $0 = DIS 1 = EBL$
Argument:	To make a change, enter one of the following:
	0# = Disabled. 1# = Enabled.
	To display the present value, and to change the value, enter the command and argument in sequence.

## 3.7.16 55# - LF to CR Conversion

Purpose:	To append a CR (Carriage Return) character to each LF (Line Feed) character when the Minifile writes a file to diskette.	
	Used to write an ASCII Text file, where the LF is the EOB or EOL character and the CR is not received. Also used to communicate with an IBM-XT or $-$ AT.	
Commands:	<ul><li>55## = displays the current parameter setting.</li><li>55# = selects parameter for setting.</li></ul>	
Display:	LFCR $0 = DIS 1 = EBL$	
Argument:	To make a change, enter one of the following:	
	0# = Disabled. 1# = Enabled.	

To display the present value, and to change the value, enter the command and argument in sequence.

3.7.17	57# - Channel 0 Auto Enable	
	Purpose:	To permit any Channel 0 protocol to operate in the hardware as well as software handshake mode.
	Commands:	<ul><li>57## = displays the current parameter setting.</li><li>57# = selects parameter for setting.</li></ul>
	Display:	CHAN0 AUTO ENABLE 0 = DIS 1 = EBL
	Argument:	To make a change, enter one of the following:
		0# = Disabled. 1# = Enabled.
		To display the present value, and to change the value, enter the command and argument in sequence.
		In the Data In Mode (Write), the Channel 0 CTS (Clear To Send) line is always true and Auto Enable has no effect (see the individual protocol specifications in Appendix B).
		In the Data Out Mode (Read), the host system can control data flow with the RTS (Request To Send) signal as well as ASCII characters DC1 DC3.
3.7.18 58# - Channel 1 Auto Enable		
	Purpose:	To permit any Channel 1 protocol to operate in the hardware as well as software handshake mode.

Commands:58## = displays the current parameter setting.58# = selects parameter for setting.

Display:	CHAN1 AUTO ENABLE 0 = DIS 1 = EBL
Argument:	To make a change, enter one of the following:
	0# = Disabled. 1# = Enabled.
	To display the present value, and to change the value, enter the command and argument in sequence.
	In the Data In Mode (Write), Channel 1 waits to receive data (Auto Enable has no effect).
	In the Data Out Mode (Read), data out takes the CTS (Clear To Send) signal true as well as any software handshake for the Minifile to send ASCII character DC3. CTS false will stop transmission.

# 3.7.19 61# - Channel 0 Stop Bits

Purpose:	To display or change the amount of stop bits for Channel 0.
Commands:	<ul><li>61## = displays the current parameter setting.</li><li>61# = selects parameter for setting.</li></ul>
Display:	CH0 STP BT 1 = ONE 2 = TWO, 3 = 1.5:
Argument:	To make a change, enter one of the following:
	1# = 1 2# = 2 3# = 1.5

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.7.20 62# - Channel 1 Stop Bits

Purpose:	To display or change the amount of stop bits for Channel 1.	
Commands:	<ul><li>62## = displays the current parameter setting.</li><li>62# = selects parameter for setting.</li></ul>	
Display:	CH1 STP BT 1 = ONE 2 = TWO, 3 = 1.5:	
Argument:	See 3.7.7.19 Argument.	

## 3.7.21 65# - Channel 0 Data Bits

**Purpose:** To display or change the amount of data bits per character for Channel 0.

**Commands: 65**## = displays the current parameter setting.

**65**# = selects parameter for setting.

Display:	CH0 DATA BITS 5, 6, 7 OR 8:	
Argument:	To make a change, enter one of the following:	
	5# = 5 data bits. 6# = 6 data bits. 7# = 7 data bits. 8# = 8 data bits.	
	To display the present value, and to change the value, enter the command and argument in sequence.	

## 3.7.22 66# - Channel 1 Data Bits

Purpose:	To display or change the amount of data bits per character for Channel 1.	
Commands:	<ul><li>66## = displays the current parameter setting.</li><li>66# = selects parameter for setting.</li></ul>	
Display:	CH1 DATA BITS 5, 6, 7 OR 8:	
Argument:	See 3.7.21 Argument.	

## 3.8 SPECIAL PURPOSE COMMANDS

This section describes the Special Purpose Commands available on the Minifile.

## 3.8.1 8# - Forward Search

Purpose:	To perform a forward search of an open file for a line beginning with the user- entered character string. To use this command the Channel 2 (parallel port) must be the active channel.
Display:	One of the following:
	PARALLEL PORT NOT SELECTED SELECT FILE NOT OPEN SEARCH FWD
	After entering a string of up to 16 characters at the SEARCH FWD prompt, the following is displayed.
	SEARCHING FOR (string)
	Then one of the following:
	FOUND (string) UNABLE TO FIND (string)

**Argument:** Enter up to 16 characters, including spaces. The characters <u>must</u> be at the beginning of a line. The Minifile automatically changes to the alphanumeric input mode, then reverts to the numeric input mode at the end of the search.

If UNABLE TO FIND is displayed, the pointer position will not change. The UNABLE TO FIND display may be due either to the string not being present forward of the present position or due to an incorrect input.

## 3.8.2 9# - Reverse Search

Purpose:	To perform a reverse search of a pen file for a line beginning with the user- entered character string. To use this command the Channel 2 (parallel port) must be the active channel.	
Display:	One of the following:	
	PARALLEL PORT NOT SELECTED SELECT FILE NOT OPEN SEARCH REV	
	After entering a string of up to 16 characters at the SEARCH REV prompt, the following is displayed.	
	SEARCHING FOR (string)	
	Then one of the following:	
	FOUND (string) UNABLE TO FIND (string)	
Argument:	Enter up to 16 characters, including spaces. The characters <b><u>must</u></b> be at the beginning of a line. The Minifile automatically changes to the alphanumeric input mode, then reverts to the numeric input mode at the end of the search.	
	If UNABLE TO FIND is displayed, the pointer position will not change. The UNABLE TO FIND display may be due either to the string not being present to the reverse of the present position or due to an incorrect input.	

3.8.3	50# - C	Date
	Purpose:	To display or change the current date.
	Commands:	<ul><li>50## = displays the current setting.</li><li>50# = selects function for setting.</li></ul>
	Display:	DATE
	Argument:	To make a change, enter the date in the DDMMYY format. For example, 4 May 1990 would be 040590.

## 3.8.4 54# - Select Drive

**Purpose:** To display or select a diskette drive in a dual-drive configuration.

Commands:	<ul><li>54## = displays the current setting.</li><li>54# = selects function for setting.</li></ul>	
Display:	SELECT DRIVE:	
Argument:	To make a change enter one of the following:	
	0# = Drive 0 Enabled. 1# = Drive 1 Enabled. 2# = Drive 2 Enabled (for Minifile Plus; Drive 1 is not used - See Section 3.9)	
	Drive 0 is the top diskette drive; Drive 1 or 2 is the bottom diskette drive. Single drive units must always be set to 0#.	

To display the present value, and to change the value, enter the command and argument in sequence.

3.8.5	56# - Parallel Looping Option		
	<b>Purpose:</b> To allow a file to be transmitted repeatedly until it is closed with a Close command (3#).		
	Commands:	<ul><li>56## = displays the current setting.</li><li>56# = selects function for setting.</li></ul>	
	Display:	PARALLEL LOOPING 0 = DIS, 1=EBL	
	<b>Argument:</b> To make a change, enter one of the following:		
	0# = Disabled. 1# = Enabled.		
With 56# 1#, when the Minifile reads the SUB character, it automatic moves to the beginning of the file. When rewind tape commands are u end-of-program codes, this parameter should be disabled. When the M comes to the end of a text file, the trailer and leader characters are tran then the file starts over. For binary files, the last character of the file is constantly transmitted until the file repositions to start.		With 56# 1#, when the Minifile reads the SUB character, it automatically moves to the beginning of the file. When rewind tape commands are used in end-of-program codes, this parameter should be disabled. When the Minifile comes to the end of a text file, the trailer and leader characters are transmitted, then the file starts over. For binary files, the last character of the file is constantly transmitted until the file repositions to start.	
		To display the present value, and to change the value, enter the command and argument in sequence.	

## 3.8.6 59# - LCD Adjustment

Purpose:	To change the viewing angle of the LCD.
Commands:	<b>59</b> ## = displays the current setting. <b>59</b> # = selects function for setting.
Display:	LCD ADJUSTMENT:

**Argument:** Once the parameter is displayed, the Enter Key (#) is pressed to cycle through the available settings in ascending order, starting with the current value. The presently stored parameter will be displayed upon first pressing the Enter Key (#). The available settings are 0 through 15 and, after reaching 15, the next displayed value is 0. The selected value should be stored with the Store Parameters command (42#). The asterisk (\*) may be used to cease the adjustment and end the command.

## 3.8.7 60# - PROM ID Display To verify the checksum value of the Minifile firmware. **Purpose: Display:** PROM CODE: (nnnnn) No argument required. The value "(nnnnn)" indicates the five-character **Argument:** PROM Code. 3.8.8 67# - Nulls in Text File **Purpose:** To allow the recording of null characters onto the diskette. **Commands: 67**## = displays the current setting. **67**# = selects function for setting. **Display:** NULL IN TXT FILE 0 = DIS 1 = EBL**Argument:** To make a change, enter one of the following: 0# = Disabled.1# = Enabled.When enabled, null characters sent to the Minifile will be recorded onto the diskette. When disabled (the default), the null characters are removed prior to the recording data onto the diskette. The TEXT FILE TYPE command (51#) (see 3.7.13) must be enabled for this command to apply. To display the present value, and to change the value, enter the command and argument in sequence. 3.8.9 68# - Mazak Conversational Terminator To set the Minifile to wait for either one or two terminators at the end of each Durnose

Turpose.	command packet. This command only applies if Protocol <b>16</b> # is active (see Appendix B).	
Commands:	<ul><li>68## = displays the current setting.</li><li>68# = selects function for setting.</li></ul>	
Display:	SINGLE MAZAK EOT 0 = DIS 1 = EBL	
Argument:	To specify two terminators (the default), enter $0#$ . To specify one terminator, enter $1#$	

## 3.8.10 69# - Serial Search

Purpose:	To make a forward search to output the contents of a file, beginning with the user-entered string. This command must be entered before the file is opened.
Display:	SERIAL SEARCH:
Argument:	To make the search, enter up to 16 alphanumeric characters directly after the colon, then open the file with the <b>2</b> # or <b>7</b> # command. This command can only work on Channel 0 or Channel 1. Three error messages can be displayed:
	PARALLEL PORT ENABLED if Channel 2 is selected; FILE ALRADY OPEN if this command is entered after the file has been opened; or NO SUBJECT FOR SEARCH if a second pound sign (#) is entered without a string.

3.8.11	70# - Numeric Input	
	Purpose:	To set the keypad to allow numeric entries.
	Display:	NUMERIC INPUT
	Argument:	No argument required.

## 3.8.12 71# - Alphanumeric Input

- **Purpose:** To set the keypad to allow alphabetic entries.
- **Display:** ALPHA INPUT
- Argument: All entries must have two numerals. Numeric entries 0 through 9 are input as 00 through 09. Alpha entries A through z are input as 10 through 35. Other available characters are input as 36 through 58 [all numbers above 58 print a diagonal slash (/)]. Table 3.8.12-1 lists the acceptable entries.

## Table 3.8.12-1. Alphanumeric Entries

Character	Entry	Character	Entry	Character	Entry
0	00	К	20	_	40
1	01	L	21	*	41
2	02	М	22	~	42
3	03	N	23	&	43
4	04	0	24	#	44
5	05	Р	25	@	45
6	06	Q	26	!	46
7	07	R	27	%	47
8	08	S	28	Ľ	48
9	09	Т	29	(	49

Character	Entry	Character	Entry	Character	Entry
A	10	U	30	)	50
В	11	V	31	- (dash)	51
С	12	W	32	{	52
D	13	Х	33	}	53
E	14	Y	34	?	54
F	15	Z	35	\$	55
G	16	. (period)	36	: (colon)	56
Н	17		37	, (comma)	57
I	18	<	38	(space)	58
J	19	>	39		

## 3.8.13 72# - Parallel Port Leader/Trailer Character

Purpose:	To select the character that will be output through the Parallel Port before and after a Text Type File.	
Commands:	<ul><li>72## = displays the current setting.</li><li>72# = selects function for setting.</li></ul>	
Display:	CH2 LDR/TRLR $0 = \text{NUL} \ 1 = \text{SPACE}:$	
Argument:	To select a null character ( =00H), enter $0$ #; to select a space character ( =20H), enter 1#.	
	The space character will be converted to the EIA equivalent if EIA Conversion is enabled. The default leader/trailer characters are null with EIA Conversion disabled; space when enabled.	

## 3.8.14 73# - Reset

Purpose:To re-initialize the system to the Power On state.Display:R E S E T

Argument: No argument required.

## 3.8.15 74# - Part Program Pre-Display

Purpose:	To display the line being processed and up to five data lines that are to follow the present line of the part program display. If the Minifile does not have an Editor, INVALID COMMAND will be displayed.
Commands:	<ul><li>74## = displays the current setting.</li><li>74# = selects function for setting.</li></ul>
Display:	COMM PRE-DISPLAY 0 TO 5:

Argument:	To make a change, enter one of the followi	ng:
-----------	--	-----

- $0^{\#}$  = Only the present line being processed will be displayed.
- 1# = The present line and the following line will be displayed.
- 2# = The present line and the following two lines will be displayed.
- 3# = The present line and the following three lines will be displayed.
- 4# = The present line and the following four lines will be displayed.
- 5# = The present line and the following five lines will be displayed.

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.8.16 75# - Part Program Display

	Purpose:	To display the data being transmitted from the active COMM channel. If the Minifile does not have an Editor, INVALID COMMAND will be displayed.
	Commands:	<ul><li>75## = displays the current setting.</li><li>75# = selects function for setting.</li></ul>
	Display:	PART PRGRM DSPLY DIS = 1,EBL = 1:
	Argument:	To make a change, enter one of the following:
		0# = Disabled (No Display). 1# = Enabled (Display).
		If the Minifile is configured with the Editor option, a file is output simultaneously to the Editor monitor as it is transmitted from the COMM Channel.
		To display the present value, and to change the value, enter the command and argument in sequence.
3.8.17	80# - P	arallel Switch Register
	Purpose:	To display or change the Parallel Switch Register 16-bit setting (see the Application Note for specific information).
	Commands:	<ul><li>80## = displays the current setting.</li><li>80# = selects function for setting.</li></ul>
	Display:	SWITCH REG 0

**Argument:** To display the present value, and to change the value, enter the command and argument in sequence.

## 3.8.18 82# - Parallel Reader Speed

**Purpose:** To display or change the parallel reader speed (see the Application Note for specific information).

Commands:	<ul><li>82## = displays the current setting.</li><li>82# = selects function for setting.</li></ul>	
Display:	READER SPEED	
Argument:	Any whole number, 15 to 1000 inclusive.	
	To display the present value, and to change the value, enter the command and argument in sequence.	

## 3.8.19 84# - Parallel Configuration Register (future use)

Purpose:	To display or change the Parallel Configuration Register (See the Application Note for specific information; when not specified, the setting should be all zeros).	
Commands:	<ul><li>84## = displays the current setting.</li><li>84# = selects function for setting.</li></ul>	
Display:	CONFIG REGISTER	
Argument:	To display the present value, and to change the value, enter the command and argument in sequence.	

## 3.9 MINIFILE PLUS COMMANDS

3.9.1	30# - Network Communications		
	Purpose:	To display or change the active Network port.	
	Commands:	<ul><li><b>30</b>## = displays the current setting.</li><li><b>30</b># = selects function for setting.</li></ul>	
	Display:	NETWRK $0 = N$ $1 = CH0$ 2 = CH1	
	Argument:	To make a change, enter one of the following:	
		0# = None (Disabled). 1# = Channel 0 Network Port Enabled 2# = Channel 1 Network Port Enabled. To display the present value, and to change the value, enter the command and	
		To display the present value, and to change the value, enter the command and	

## 3.9.2 31# - Editor Function

Purpose:	To display or change the port the Editor will use.
Commands:	<ul><li>31## = displays the current setting.</li><li>31# = selects function for setting.</li></ul>
Display:	EDITOR $0 = N$ $1 = CH0$ 2 = CH1

argument in sequence.

**Argument:** To make a change, enter one of the following:

0# = None (Disabled). 1# = Channel 0 Port Enabled 2# = Channel 1 Port Enabled.

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.9.3 32# - Network Default Drive

Purpose:	To display or change the default drive for the Network function (the drive that will be accessed whenever the network requests a disk function).		
Commands:	<ul><li>32## = displays the current setting.</li><li>32# = selects function for setting.</li></ul>		
Display:	NETWORK DRIVE:		
Argument:	The Minifile Plus has an option for a RAM disk drive, designated Drive 2. The floppy drives maintain the same drive specifications as before (i.e., 0 and 1) but since the Minifile Plus can have only two drives, the selections are Drives 0 and 1 $\underline{or}$ Drives 0 and 2.		
	To make a change, enter one of the following:		
	0# = Drive 0 Enabled as the Default Drive. 1# = Drive 1 Enabled as the Default Drive. 2# = Drive 2 Enabled as the Default Drive.		

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.9.4 33# - Editor Default Drive

Purpose:	To display or change the default drive for the Editor function (the drive that will be accessed whenever a drive is not specified in a command statement).		
Commands:	<ul><li>33## = displays the current setting.</li><li>33# = selects function for setting.</li></ul>		
Display:	EDITOR DRIVE:		
Argument:	The Minifile Plus has an option for a RAM disk drive, designated Drive 2. The floppy drives maintain the same drive specifications as before (i.e., 0 and 1) but since the Minifile Plus can have only two drives, the selections are Drives 0 and 1 <u>or</u> Drives 0 and 2.		
	To make a change, enter one of the following:		
	0# = Drive 0 Enabled as the Default Drive. 1# = Drive 1 Enabled as the Default Drive. 2# = Drive 2 Enabled as the Default Drive.		

To display the present value, and to change the value, enter the command and argument in sequence.

## 3.9.5 54# - Select Drive

Purpose:	To display or select the diskette drive in a dual-drive configuration used for Machine Tool communications and keypad commands.	
	The Editor format disk (FOR) and create directory (CRE) commands now require that a disk drive be specified in the command statement, along with a volume name. For example:	
	FOR D2:TEST or CRE D1:TEST	
	The Editor will not allow these commands if any files are open in the Network or Machine Tool communications.	
Commands:	<ul><li>54## = displays the current setting.</li><li>54# = selects function for setting.</li></ul>	
Display:	SELECT DRIVE:	
Argument:	The Minifile Plus has an option for a RAM disk drive, designated Drive 2. The floppy drives maintain the same drive specifications as before (i.e., 0 and 1) but since the Minifile Plus can have only two drives, the selections are Drives 0 and 1 <u>or</u> Drives 0 and 2.	
	To make a change, enter one of the following:	
	0# = Drive 0 Enabled as the Default Drive. 1# = Drive 1 Enabled as the Default Drive. 2# = Drive 2 Enabled as the Default Drive.	
	To display the present value, and to change the value, enter the command and argument in sequence.	

## 3.9.6 63# - Protocol PROM Version

Purpose:	To display or change the Minifile Plus PROM version.
Display:	PROTOCOL PROM VERSION NN.NN
Argument:	No argument required. The "NN.NN" indicates the version number.
	To display the present value, and to change the value, enter the command and argument in sequence.
	The Minifile Plus has a separate PROM for the serial protocols which was incorporated to allow the user to acquire additional protocols or a special protocol to allow upgrades without changing the basic operation of the Minifile.

# **APPENDIX A - SPECIFICATIONS**

## A1. PHYSICAL CONFIGURATION

А.	Size:		
		Portable:	5.25"H X 10"W X 10.5"D
			(13.33cm X 25.4cm X 26.67cm)
		Rack-Mount	5.25"H X 19.0"W X 8.75"D
			(13.33cm X 48.26cm X 22.22cm)
D	<b>XX</b> 7 • 1 /		
В.	Weight:	Portable:	12 lbs (5 44 kg)
			12 105 (0.11 145)
		Deals Mount	11  Hz(5.01-)
		Rack-Mount	11 lbs (5.0 kg)
C.	Display:		32 alphanumeric LCD
D.	Keyboard	l:	3 X 4 character keypad; 0-9, #, * characters
E.	Number of	of Drives:	One standard, one optional
F.	Recording	g Medium:	3.5" diskette; 5.25" diskette
C	Stars of C	- 	
G.	Storage C	apacity:	
	ł	P-XT:	3,000° of tape (360 KB)
	I	P-3:	6,000' of tape (720 KB)
	I	P-AT:	10,000' of tape (1.2 MB)
	I	PS/2:	12,000' of tape (1.44 MB)
	I	P-27:	23,000 of tape (2.7 MB)

## A2. INPUT POWER

A.	Voltage:	90 to 264 VAC
B.	Frequency:	47 to 63 Hz
C.	Amperage:	0.5 A

## A3. ONLINE STATISTICS

A.	MTBF:	10,000 operating hours
B.	MTTR:	60 minutes

## A4. ENVIRONMENT

A.	Operating Temperature:	50°F to 115°F (10°C to 46.1°C)
B.	Shipping Temperature:	40°F to 144°F (4.4°C to 62.2°C)
C.	Storage Temperature:	-8°F to 117°F (-22.2°C to 47.2°C)
D.	Relative Humidity:	20% to 80%
E.	Maximum Wet Bulb:	78°F (25.5°C)

## A5. DATA CHARACTERISTICS

A.	Data Types:	ASCII, Binary, EIA/ASCII Conversion
B.	Stop Bits:	1, 1.5, or 2
C.	Data Bits:	5, 6, 7, or 8
D.	Serial Baud Rates:	50, 75, 110, 135, 150, 300, 600, 750, 1000, 1200, 1500, 1800, 2000, 2400, 3000, 3600, 4800, 7200, or 9600 BPS
E.	Parity:	None, Odd, Even Mark, or Space
F.	Error Rates:	
	Soft:	Recovered internally
	Hard (Read):	1 per 1-trillion bits

## A6. INTERFACES

A.	RS-232-C	
	Connectors:	DB25S (female) serial modem port (DCE) DB25P (male) serial terminal port (DTE)
	Baud Rates, Stop Bits, Data Bits, Parity:	See A5.
	Protocols:	No Protocol; X/On X/Off; Bridgeport Editor Port; Bridgeport DNC Loader; Bridgeport Easy Link; RS-491, Level II, Slave; Heidenhain; Punch/Reader; Synchronous Reader; RS-491, Level I; Fanuc; Heidenhain Block; FAPT; HECC-80; RS-491, level II, Master; Hitachi Seiki; Mazak Conversational; Punch/Reader master; X/On X/Off II; TLM; Sharnoa Remote; Fanuc Cassette; Mazak Cassette; Acramatic
В.	Parallel Reader/Punch (PR/P):	
	Connector	50-pin Telco-type (female)
	Function:	Tape reader and tape punch emulation
	Character Rate:	15 to 1000 cps
	Characteristic:	8-bit parallel data

## B1. OVERVIEW

This Appendix describes the protocols available on the Minifile, including the argument used to call the protocol when command **47**# or **48**# are used (see Section 3) and the default options automatically called in by the protocol. The available protocols are listed numerically according to the ascending call numbers.

## B2. MINIFILE PROTOCOLS

Protocol	Argument
No Protocol	0#
X/On X/Off	1#
Bridgeport Editor Port	2#
Bridgeport DNC Loader	3#
Bridgeport Easy Link	4#
RS-491, Level II, Slave	5#
Heidenhain	6#
Punch/Reader	7#
Synchronous Reader	8#
RS-491, Level I	9#
Fanuc	10#
Heidenhain Block	11#
FAPT	12#
HECC-80	13#
RS-491, Level II, Master	14#
Hitachi Seiki	15#
Mazak Conversational	16#
Punch Reader/Master	17#
X/On X/Off II	18#
TLM	19#
Sharnoa Remote	20#
Fanuc Cassette	21#
Mazak Cassette	22#
Acramatic	23#
Host System (Optional)	24#

## **B3. PROTOCOL SELECTION**

In order to enter or change a protocol for Channel 0, **47**# must be used (see Section 3, paragraph 3.7.10); for Channel 1, **48**# must be used (see Section 3, paragraph 3.7.11).

## B3.1 0# - No Protocol

Receive Data:	The Minifile waits to receive data from the host system. No ASCII character is required. When the transfer is completed, the file must be closed with the Close File command ( <b>3</b> #).
Transmit Data:	The Minifile transmits data as soon as the file is opened. No ASCII character is required.
Parameter Defaults:	No Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA Conversion and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop Bits.

## B3.2 1# - X/On X/Off

Receive Data:	The Minifile waits to receive data from the host system. No ASCII character is required. Once the transfer is completed, the file must be closed with the Close File command $(3\#)$ .
Transmit Data:	The Minifile transmits data as soon as the file is opened. No ASCII character is required. The host system can suspend the data transfer by transmitting the ASCII character DC3, and then resume data transmission with a DC1.
Parameter Defaults:	Even Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA Conversion, and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.3 2# - Bridgeport Editor Port

(Specifications available from Bridgeport Machines, Inc.)

Parameter Defaults:No Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA<br/>Conversion, and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop<br/>Bits.

## B3.4 3# - Bridgeport DNC Loader

(Specifications available from Bridgeport Machines, Inc.)

Parameter Defaults:No Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA<br/>Conversion, and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop<br/>Bits.

## B3.5 4# - Bridgeport Easy Link

(Specifications available from Bridgeport Machines, Inc.)

Parameter Defaults:Even Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA<br/>Conversion, and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop<br/>Bits.

## B3.6 5# - RS-491, Level II, Slave

Receive Data:	When the ASCII character DC2 is received from the host system, the Minifile transmits the ASCII character DC1 to indicate it is ready to receive data. When the transfer is completed, the host system may send an ASCII EOT (End of Transmission) followed by a DC4. The Minifile than transmits a DC3 and closes the file. If the host system cannot send an EOT and a DC4, then the Close File Command (3#) must be used.
Transmit Data:	When the Minifile receives the ASCII Character DC1 from the host system, it transmits the data, preceded by null characters, and followed by more null characters and an EOT. The host system can suspend the data transfer by transmitting the ASCII character DC3, and then resume data transmission with a DC1.
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.7 6# - Heidenhain

Receive Data:	The Minifile waits to receive data from the host system. No ASCII character is required. Once the transfer is completed, the host system may send an ASCII ETX to close the file. If the host system cannot send an ETX, the file must be closed with the Close File command (3#		
Transmit Data:	When the Minifile receives the ASCII character DC1 from the host system, the Minifile transmits data. The host system can suspend the data transfer by transmitting an ASCII character DC3, and then resume data transmission with a DC1. When the transmission is completed, the Minifile transmits an EOT and closes the file.		
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.		

## B3.8 7# - Punch/Reader

<b>Receive Data:</b>	When the ASCII character DC2 is received from the host system, the					
	Minifile starts recording data. The ASCII character DC4 is sent to stop					
	the Minifile recording until another DC2 is sent. This DC2/DC4					

	combination serves as a Punch On/Punch Off. Once the transmission is completed, the file must be closed by entering the Close File command ( <b>3</b> #).
Transmit Data:	When the Minifile receives the ASCII character DC1 from the host system, the Minifile transmits data preceded by nulls. The host system can suspend the data transfer by transmitting an ASCII character DC3, and then resume data transmission with a DC1. When the transmission is completed, the Minifile transmits null characters (blank spaces) and closes the file.
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.9 8# - Synchronous Reader

(This protocol is for Channel 0 use exclusively.)

Receive Data:	The Minifile waits to receive data from the host system. No ASCII character is required. Once the transfer is completed, the file must be closed by entering the Close File command (3#).			
Transmit Data:	When the host system sets REQUEST TO SEND to the active (high) state, the Minifile can transmit a data character. The REQUEST TO SEND must be set to high each time a character is sent to the host system.			
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.			

## B3.10 9# - RS-491, Level I

Receive Data:	If Channel 0 is active, the host system does not send an ASCII character, so the Minifile waits until data are sent. If Channel 1 is active, data is recorded when the DATA CARRIER DETECT is in the active (high) state. Once the transmission is completed, the file must be closed by entering the Close File command ( <b>3</b> #).
Transmit Data:	The Minifile can transmit data when the REQUEST TO SEND (for Channel 0) or the CLEAR TO SEND (for Channel 1) is set to high. The host system releases the high signal whenever it needs to halt transmission. If the transition starts while a character is being sent, the Minifile completes the character transfer.
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.11 10# - Fanuc

Receive Data:	When the ASCII character DC2 is received from the host system, the Minifile starts recording data. When the transmission has been completed, the host system may send an ASCII character DC4 to close the file. If the host system cannot send a DC4, the file must be closed by entering the Close File command ( <b>3</b> #).
Transmit Data:	When the host system transmits an ASCII character DC1, the Minifile starts transmitting data preceded by nulls. The host system can suspend the data transfer by transmitting an ASCII character DC3, and then resume data transmission with a DC1. The Minifile transmits null characters (blank spaces) to show the transmission has been completed.
Parameter Defaults:	Even Parity; Text (ASCII) File Type Enabled; Line Feed Output and EIA Conversion Disabled; LF to CR Conversion Enabled; 7 Data Bits; 2 Stop Bits.

## B3.12 11# - Heidenhain Block

(This information is proprietary.)

Parameter Defaults:Even Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA<br/>Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop<br/>Bits.

## B3.13 12# - FAPT

(This information is proprietary.)

Parameter Defaults:No Parity; Text (ASCII) File Type; Line Feed Output, EIA Conversion<br/>and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop Bits.

## B3.14 13# - Heidenhain Block

(This information is proprietary.)

Parameter Defaults:Even Parity; Text (ASCII) File Type and Line Feed Output Enabled;<br/>EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2<br/>Stop Bits.

## B3.15 14# - RS-491, Level II, Master

**Receive Data:** When the Minifile transmits the ASCII character DC1, it starts recording data. When the transmission is completed, the file must be closed by entering the Close File command (**3**#).

Transmit Data:	The Minifile transmits the ASCII character DC2. When the host system transmits the ASCII character DC1, the Minifile begins transmitting data. The host system can suspend the data transfer by transmitting the ASCII character DC3, and then resume transmission with a DCf1. At the end of transmission the Minifile transmits an ASCII character EOT followed by a DC4 to close the file.
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.16 15# - Hitachi Seiki

(This information is proprietary.)

Parameter Defaults:No Parity; Text (ASCII) File Type; Line Feed Output and EIA<br/>Conversion and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop<br/>Bits.

## B3.17 16# - Mazak Conversational

(This information is proprietary.)

Parameter Defaults:No Parity; Text (ASCII) File Type; Line Feed Output, EIA Conversion<br/>and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop Bits.

## B3.18 17# - Punch/Reader Master

Receive Data:	The Minifile initiates transmission by sending ASCII character DC1 to the host system. If fifty consecutive null characters are received, the Minifile sends ASCII character DC3 and closes the file. Otherwise, the Close file command ( <b>3</b> #) must be used.		
Transmit Data:	The Minifile transmits ASCII character DC2 to the host system. The host system then transmits ASCII character DC1 to start transmission. The host system can suspend the data transmission by sending ASCII character DC3, and then resume transmission by sending a DC1. The Minifile signals the transmission is completed with ASCII character DC4.		
Parameter Defaults:	Even Parity; Text (ASCII) File Type and Line Feed Output Enabled; EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.		

## B3.19 18# - X/On X/Off II

Receive Data:	The Minifile waits to receive data from the host system. No ASCII				
	character is required. When the transfer has been completed, the file				
	must be closed with the Close File command (3#).				

Transmit Data:	The Minifile transmits ASCII character DC1, then transmits data. The host system can suspend the data transfer by transmitting the ASCII character DC3, and then resume data transmission with a DC1.
Parameter Defaults:	Even Parity; Text (ASCII) File Type Enabled; Line Feed Output, EIA Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop Bits.

## B3.20 19# - TLM

(This information is proprietary.)

Parameter Defaults:No Parity; Text (ASCII) File Type and LF Output Enabled; EIA<br/>Conversion Disabled; and LF to CR Conversion Enabled; 8 Data Bits;<br/>2 Stop Bits.

## B3.21 20# - Sharnoa Remote

(This information is proprietary.)

Parameter Defaults:Even Parity; Text (ASCII) File Type and LF Output Enabled; EIA<br/>Conversion and LF to CR Conversion Disabled; 7 Data Bits; 2 Stop<br/>Bits.

## B3.22 21# - Fanuc Cassette

(This information is proprietary.)

Parameter Defaults:Even Parity; Text (ASCII) File Type Enabled; LF Output and EIA<br/>Conversion Disabled; LF to CR Conversion Enabled; 7 Data Bits; 2<br/>Stop Bits.

## B3.23 22# - Mazak Cassette

(This information is proprietary.)

Parameter Defaults:No Parity; No Text (ASCII) File; Line Feed Output, EIA Conversion<br/>and LF to CR Conversion Disabled; 8 Data Bits; 2 Stop Bits.

## B3.24 23# - Mazak Cassette

(This information is proprietary.)

## B3.25 Host System (Optional)

The Minifile must be configured with the Host Control Protocol for this selection. If so configured, see the Host Control Protocol Operator's Manual provided with the system.

## C1. OVERVIEW

This Appendix lists and explains the error message presently available on the Minifile.

## C2. ERROR MESSGES AND THEIR MEANINGS

## C2.1 COMM ERROR

The Minifile detected a framing error when receiving data. Usually a baud rate, data bit, parity bit, or stop bit error.

## C2.2 DATA OVERRUN

Serial data overran the available buffer space. Usually caused by too many soft seek errors that extend latency.

## C2.3 DEFINED FILE ALREADY EXISTS

An attempt was made to create a file with the same name as an existing file.

## C2.4 DIRECTORY FAILURE

The Minifile is unable to read the directory. Usually the diskette is not properly formatted, or data on the diskette has been lost.

## C2.5 DISK READ ERROR

The Minifile attempted to read a block four times without success.

## C2.6 DISK TIMEOUT

Diskette operation was not completed in time. Usually means there is no diskette in the drive or the incorrect drive was selected (see the **54**# command in Section 3).

## C2.7 END OF MEDIUM

The diskette had no room available for the transmitted data.

## C2.8 FILE DOES NOT EXIST

A non-existent file was requested by directory file name. Must contain the .**TXT** extension if the **51**# command is enabled; the **.BIN** extension if the **51**# command is disabled (see Section 3.)

## C2.9 FILE OPEN

A command was issued while the file was open.

## C2.10 INVALID COMMAND

The Minifile did not recognize the command.

## C2.11 INVALID DATE ENTERED

The entered date did not conform to the day (01-31) and/or month (01-12) range.

## C2.12 INVALILD DATE FORMAT DDMMYY

The date was entered with an invalid format (not two numerals each for the day, month, and year.)

## C2.13 INVALID FILE NUMBER ENTERED

A non-existent file was requested by directory file number.

## C2.14 INVLAID VALUE ENTERED

An invalid argument was entered for a command.

## C2.15 READ-ONLY FILE

The Minifile attempted to delete a read-only file (set by the DOS ATTRIB command.)

## C2.16 SYSTEM NOT CONFIGURED

The stored parameters were lost or not saved in non-volatile memory (enter 42# to continue.)

## C2.17 THE DIRECTORY IS FULL

The maximum number of files are already written to the diskette.

## C2.18 TRACK SEEK ERROR

The Minifile attempted to verify the track position four times without success.

## C2.19 WRITE PROTECT

The Minifile attempted to write to a write-protected diskette.

## D1. OVERVIEW

The following procedures cover the basic maintenance to support the Minifile's MTBF, MTTR, and Greco System's in-warranty and out-of-warranty service. Field repair to the Minifile is <u>not</u> recommended. Rather, a Return Material Authorization (RMA) number should be acquired from Greco Systems (see the RETURN MATERIAL AUTHORIZATION procedures in the front of the manual.)

## WARNING

Do not remove the Minifile's cover, as a potential shock hazard is present. If the Minifile cover must be removed, the AC power must be disconnected prior to opening the unit.

## D2. BASIC MAINTENANCE

The main areas to be maintained on the Minifile are the exterior of the unit, the read/write heads on the diskette drives, and the filter on the air circulating fan.

## D2.1 Minifile Exterior Maintenance

Perform the following:

- 1. Prepare a solution of clean water and a mild liquid detergent.
- 2. Dampen, but do not wet, a clean, lint-free cloth with the cleaning solution.
- 3. Carefully clean the outer surfaces, making certain no dampness seeps into the interior of the unit.
- 4. Go over the same area with a fresh, dampened (detergent- and lint-free) cloth to remove the remaining dirt and detergent.
- 5. Dry the unit with a clean, dry, lint-free cloth.
- 6. Without disassembling the unit, remove dirt and dust from accessible interior surfaces with low-pressure vacuuming.

## D2.2 Floppy Diskette Drive Read/Write Head Maintenance

Clean the Read/Write heads of the floppy diskette drives with the Greco System's Head Cleaning Kit, Part #957-001 for 3.5" diskettes or Part #957-005 for 5.25" diskettes. Cleaning intervals are dependent upon the amount of contamination in the area but, at minimum, the Read/Write heads should be cleaned each time there is a sequence of repeated read errors.

To use the kit, perform the following:

- 1. Insert the proper element into the Minifile's diskette drive slot.
- 2. Enter the **96**# command.
- 3. Wait approximately three minutes.
- 4. End the cleaning cycle with the **73**# command.

5. Remove the element from the Minifile's diskette drive slot.

## D2.3 Air Filter Maintenance

Perform the following:

- 1. Inspect the fan air filter every week for contamination (inspect the filter daily if the Minifile is used in a contaminated area.)
- 2. When contamination could restrict air flow, remove the filter by gently prying off the black plastic baffle (do **not** remove any screws.0
- 3. Clean the filter with a solution of clean water and a mild liquid detergent.
- 4. Thoroughly rinse the filter in clean water.
- 5. Thoroughly air or blow dry the filter.
- 6. If the air filter requires replacement, use a Greco Systems' Part #935-002 filter.
- 7. Place the filter in the Minifile filter assembly, then press the baffle back into position.

## D3. MINIFILE SERVICE

## D3.1 Servicing Recommendations

Field repair to the Minifile is <u>not</u> recommended. The best service can be obtained by returning the Minifile to Greco Systems. When the unit is still under warranty the Minifile must, in most cases, be returned to Greco Systems is the warranty is to be honored (see the RETURN MATERIAL AUTHORIZATION procedures in the front of the manual.)

## D3.2 Minifile Repackaging Procedures

To return a Minifile for service it should be packaged as follows, as in-transit damage is not covered by Greco Systems:

- 1. Remove the power cord and all data cables, then seal the power cord and cables in a clean plastic bag (it is not necessary to return the power cord unless a problem with the cord is suspected.)
- 2. Re-insert the Read/Write Head protector that came with each drive. The protector should be slipped carefully into the diskette drive slot and locked in place to protect the Read/Write Heads from vibration or shock.
- 3. Enclose the unit in a clean plastic bag and tape the bag closed to prevent contamination by the packing materials.
- 4. Tape the bag with the cables, etc., to the top of the bagged unit.
- 5. Place the padding around the unit.

## <u>NOTE</u>

If the original Minifile shipping Container and padding are available, perform steps 5 and 6. If the original Minifile shipping container and padding are <u>not</u> available, perform steps 7 and 8.

- 6. Place the unit in the original shipping container.
- 7. Tape a piece of cardboard completely around the bagged unit to protect all surfaces.

- 8. Place the unit in the center of a strong shipping container with at least six inches of loose styrofoam-type pellets on each side of the unit.
- 9. Place the paperwork, including the RMA number and all pertinent information, in a separate plastic bag. Ensure the information is placed within the unit away from the walls of the carton so the information cannot be cut when the carton is opened.
- 10. Seal the carton with strong packing tape and mark **FRAGILE** on all sides.
- 11. Mark the RMA number on the shipping label.
- 12. Ensure the carton is sufficiently insured to cover all costs in the event the unit is damaged or lost.
- 13. Contact Greco Systems for address to ship the carton by prepaid freight.

## E1. OVERVIEW

The terms listed in this Appendix are commonly used with the Minifile.

## E2. TERMS AND THEIR DEFINITIONS

## E2.1 Argument

A variable that gives a Command (see below) the information needed to perform an operation.

## E2.2 ASCII (American Standard Code for Information Interchange) Code

A 7-bit code of alphanumeric and control characters.

## E2.3 Baud

The data transmission rate in bits per second.

## E2.4 Bit

A binary digit; either a one or a zero.

## E2.5 CNC (Computer Numerical Control)

The use of computers for machine tool control. This technology makes available programmable host/control interfaces, extended memory storage, editing capabilities, and Distributed Numerical Control (see DNC.)

## E2.6 Command

An instruction to the Minifile.

## E2.7 CR (Carriage Return)

An ASCII character usually combined with a LF Character (see below) to mark the end of a line. The CR causes a printer or display screen to move its left-most position.

## E2.8 Data Bits

Ones and/or zeros that are grouped to form a character.

## E2.9 DCE (Data Communications Equipment)

One of the two hardware interfaces resulting from the RS-232-C standard (also see DTE.)

## E2.10 DNC (Distributed Numerical Control; also, Direct Numerical Control)

**Distributed Numerical Control:** Communications technology that connects CNC machine tools to a central computer to control and distribute part programs.

**Direct Numerical Control:** Incremental loading of a part program into a machine tool during a machining process.

## E2.11 DTE (Data Terminal Equipment)

One of the two hardware interfaces resulting from the RS-232-C standard (also see DCE.)

## E2.12 EIA (Electronic Industries Association) Code

An NC/CNC industry standard for the data format of part programs (RS-244.)

## E2.13 Enter Key

The pound sign (#) key located on the Minifile keypad.

## E2.14 Erase Key

The asterisk (\*) key located on the Minifile keypad.

## E2.15 File

A group of data specified by an alphabetic, numeric, or alphanumeric file name.

## E2.16 Formatting

The organizing of storage locations on a medium, such as a hard disk, floppy diskette, or magnetic tape.

## E2.17 LF (Line Feed)

An ASCII character which is usually combined with a CR character (see above) to mark the end of a line. The LF causes a printer or display screen to advance to the next line.

## E2.18 NC (Numerical Control)

A device that controls the machining of a part using numerically coded programs. A method of coding the positioning and contouring techniques involved in machining.

## E2.19 Parallel Interface

The link between (two devices in which the data and control signals (bits) for each character are transmitted simultaneously on separate lines.)

## E2.20 Parity

A method of data transmission error checking.

## E2.21 Pointer

The Minifile firmware method of keeping track of the specific file location presently being used.

## E2.22 Protocol

The rules for data transmission between two computers or devices.

## E2.23 RS-232-C

An EIA standard defining the electrical and hardware characteristics for data transmission between the DCE and DTE interface.

## E2.24 Serial Interface

The link between two devices in which the data and control signals (bits) for each character are transmitted in sequence over the same line.

## E2.25 Stop Bits

Bits used to signal the end of the serial transmission of a character.

## F1. OVERVIEW

The EIA/ASCII/ISO Conversion Chart in this Appendix can be used to convert EIA codes. This chart may also be used to convert ISO paper tape codes. The non-listed ASCII characters!,",',\*,;,,,? And the ASCII control codes are converted to EIA Code spaces (see 10 Hex.)

## F2. EIA/ASCII/ISO CONVERSION CHART

Character	EIA Code (Hex.)	ASCII Code (Hex.)	ISO Code* (Hex.)	Remarks/Use
(space)	10	20	A0	
\$	80	24	24	EOB IN EIA
%	5B	25	A5	EOR – Rewind Stop in ASCII
+	70	2B	2B	
3	3B	2C	N/A	(Comma)
-	40	2D	2D	(Minus)
•	6B	2E	2E	(Period)
/	31	2F	AF	
0	20	30	30	
1	01	31	B1	
2	02	32	B2	
3	13	33	33	
4	04	34	B4	
5	15	35	35	
6	16	36	36	
7	07	37	B7	
8	08	38	B8	
9	19	30	39	
=	0B	3D	BD	EOR – Rewind Stop in EIA
A	61	41	41	
В	62	42	42	
С	73	43	C3	
D	64	44	44	
E	75	45	C5	
F	76	46	C6	
G	67	47	47	

Character	EIA Code (Hex.)	ASCII Code (Hex.)	ISO Code* (Hex.)	Remarks/Use
Н	68	48	48	
I	79	49	C9	
J	51	4A	CA	
K	52	4B	4B	
L	43	4C	CC	
М	54	4D	4D	
Ν	45	4E	4E	
0	46***	4F	CF	
Р	57	50	50	
Q	58	51	D1	
R	49	52	D2	
S	32	53	53	
Т	23	54	D4	
U	34	55	55	
V	25	54	56	
W	26	57	D7	
Х	37	58	D8	
Y	38	59	59	
Z	29	5A	5A	
CR	80	0D	8D	(Carriage Return) EOB in EIA
LF	****	0A	0A	(Line Feed) EOB in ASCII (ISO)
HT	33	09	09	(Tab)
BS	2A	08	88	(Backspace)
&	0E	26	A6	
(	7C	28	28	
)	71	29	A9	
:	10	3A	3A	
@	6D	40	CO	

<sup>\*</sup> ISO Code is ASCII Code with even parity (bit 8 as the parity bit.) Since ASCII is defined as a 7bit code, "ASCII" punched paper tapes are actually using ISO Code (an 8-bit code.)

\*\*\*\* No EIA equivalent.

<sup>\*\*</sup> Converted only on output. If EIA Conversion is enabled, the Minifile records an ASCII CR (0D Hex.) if it receives an EIA value of 80 Hex.

<sup>\*\*\*</sup> If EIA Conversion is enabled, the Minifile records an ASCII: (colon – 3A Hex.) if it receives an EIA value of 46 hex.